PLANCHE 1 / FIGURE 1

PLANCHE 2 / FIGURE 2

2	50234951	Scanner assembly (cf Figure 5)
7	53090414	Right printer cover colored
11	53359501	Printer front door assembly
12	53090422	Left printer cover colored
13	50235001	Front panel support assy

PLANCHE 3 / FIGURE 3

1	51032302	Printer exit paper guide.
3	53090401	Printer back cover colored
4	53089393	Cover rear
6	50235618	Tray exit+ extend

PLANCHE 4 / FIGURE 4

4	56641542	Ferrite flat cable CIS 12 pin

PLANCHE 5 / FIGURE 5

2	53359075	Scanner frame assembly
3	56641542	Ferrite flat cable CIS 12 pin
5	50519008	CIS support (cf Figure 6)
6	51256104	CIS drive pulley colored
7	56642601	Console cord 16 pin
14	56523114	Stepper motor scanner
15	51032424	CIS slider left colored
16	56642701	CIS DL515 sp
17	51032432	CIS slider right colored
18	50937401	CIS spring

PLANCHE 6 / FIGURE 6

2	56641542	Ferrite flat cable CIS 12 pin

PLANCHE 7 / FIGURE 7

1	50235101	Paper tray unit

PLANCHE 8 / FIGURE 8

1	56522901	Brushless motor - DC24V
2	53359101	Transfer roller
3	53359201	Paper feed roller - MM32
4	51402401	Magnetic clutch -43z

PLANCHE 9 / FIGURE 9

1	50235201	Fusing unit

PLANCHE 10 / FIGURE 10

1	50235301	Laser unit
2	56215701	Micro switch
4	56420101	Power supply unit